

PLASTOMATIC




SERIES CAFE MULTI-VOLTAGE ELECTRIC ACTUATORS

Installation, operation, & maintenance instructions


CONTENTS

SAFETY INSTRUCTIONS	6
SPECIFICATIONS	7
DIMENSIONS	8
INSTALLATION	9
WIRING	11
ON/OFF	12
MODULATION	14
INPUT/OUTPUT	16
OPERATION	19
ON/OFF	27
MODULATION	37
MODBUS	47


CAFE PARTS LIST




CAFE Actuator x1



Large DIN Connector x1




Small DIN Connector
(10 o'clock Ground) x1



Small DIN Cap x1


For Shipping Purposes Only



Large DIN Cap
x1

Large DIN Cap
Ring x1

For Shipping Purposes Only




Plastic
Shroud x2


Plastic Gland
Shroud x2

Rubber Gland
x2


Small DIN
Shipping Gasket
x1




Large DIN Gasket
x1




Small DIN Gasket
x2




Cable Gland x1




Manual Handle
x1



14mm Double Square
Coupler x1



Large DIN Screw
x1



Small DIN Screw
x2



Large DIN Screw
Gasket x1




Small DIN
Screw Gasket x2




Documentation


ON/OFF CAFE NITRO PARTS LIST




CAFE NITRO Actuator x1



Large DIN Connector x1




Small DIN Connector
(10 o'clock Ground) x1




Small DIN Cap x1

For Shipping Purposes Only



Large DIN Cap
x1



Large DIN Cap
Ring x1

For Shipping Purposes Only



Plastic
Shroud x2




Plastic Gland
Shroud x2




Rubber Gland
x2




Small DIN
Shipping Gasket
x1




Large DIN Gasket
x1




Small DIN Gasket
x2




Cable Gland x1




Manual Handle
x1



14mm Double Square
Coupler x1



Large DIN Screw
x1



Small DIN Screw
x2



Large DIN Screw
Gasket x1




Small DIN
Screw Gasket x2




Documentation


CAFE NITRO W/ CONTROL PARTS LIST




CAFE NITRO Actuator x1



Large DIN Connector x1




Small DIN Connector
(10 o'clock Ground) x1



Small DIN Connector
(6 o'clock Ground) x1


For Shipping Purposes Only



Large DIN Cap
x1

Large DIN Cap
Ring x1

For Shipping Purposes Only




Plastic
Shroud x2


Plastic Gland
Shroud x2

Rubber Gland
x2


Small DIN
Shipping Gasket
x1




Large DIN Gasket
x1




Small DIN Gasket
x2




Cable Gland x1




Manual Handle
x1



14mm Double Square
Coupler x1



Large DIN Screw
x1



Small DIN Screw
x2



Large DIN Screw
Gasket x1



Small DIN
Screw Gasket x2



Documentation

SAFETY INSTRUCTIONS

Damage caused by non-compliance to these instructions will not be covered by our warranty. Read these instructions BEFORE installing or connecting the actuator. Electric actuators operate with the use of live electricity. It is recommended that only qualified electricians or people instructed in accordance with electrical engineering, and familiar with local electrical, health and safety directives, be involved in the connection of these actuators. It is strongly recommended that each actuator has its own independent fused system to protect it against the influence of other electrical devices connected to the system. Follow instructions carefully. This unit is designed to be connected to equipment which can be hazardous to persons and property if used incorrectly. Remove power to unit before wiring connections. Do not use unit if plastic enclosure is cracked or broken.




PROTECTION AGAINST ELECTRIC SHOCK. CLASS I (EARTHED DEVICE)



WARNING/CAUTION/DANGER INDICATES A POTENTIAL HAZARD. FAILURE TO FOLLOW ALL WARNINGS MAY LEAD TO EQUIPMENT DAMAGE, INJURY, OR DEATH.



ELECTROSTATIC DISCHARGE (ESD)/ ELECTROCUTION DANGER ALERTS USER TO RISK OF POTENTIAL DAMAGE TO PRODUCT BY ESD, AND/OR RISK OF POTENTIAL OF INJURY OR DEATH VIA ELECTROCUTION.



PERSONAL PROTECTIVE EQUIPMENT (PPE) ALWAYS UTILIZE THE MOST APPROPRIATE PPE DURING INSTALLATION AND SERVICE.






NOTE/TECHNICAL NOTES HIGHLIGHTS ADDITIONAL INFORMATION OR DETAILED PROCEDURE.

SPECIFICATIONS


Sizes	3/8"-2" Ball Valves	
Actuator	CAFE	CAFE NITRO
Input Voltage (+1.1 V _R / -0.85 V _R)	24 Vdc, 24 Vac, 110-240 Vac	24 Vdc, 24 Vac, 110-240 Vac
Frequency	DC, 50Hz/60Hz	DC, 50Hz/60Hz
Working Time 0-90° No Load) ±10%	5 seconds preset	5 seconds preset - up to 10 sec via display
Multivoltage Maximum Run Torque (Nm/ in-lbs.)*	15 / 133	15 / 133
Maximum Break Torque (Nm/in-lbs.)	20 / 177	20 / 177
On/Off Duty Rating %	75	75
Modulating Duty Rating %	100	100
IP Rating—IEC 60529	IP67	IP67
Working Angle Standard	90°/180°	90°/180°
Application	Indoor **	Indoor**
Temperature Range (°F / °C)	-4 to 122 / -20 to 50	-4 to 122 / -20 to 50
Anti-Condensation Heater (W)	3.5	3.5
Input Power (@24VDC)max	35 W	35 W
Current Full Load: 24Vdc, 24Vac 1p 50/60Hz, 110-240Vac 1ph 50/60Hz	1.4 A, 1.5 A, 0.3 - 0.15 A	1.4 A, 1.5 A, 0.3 - 0.15 A
Discrete Control Input	Input Power	Input Power
Analog Control Input		0-10V,2-10V,0-20mA,4-20mA
Discrete Output (Volt Free)	Relay (ON/OFF)	Relay (Programmable)
Discrete Output Activation offset	approx. 5°	approx. 5°
Analog Control Output	–	0-10V,2-10V,0-20mA,4-20mA
Analog Control Impedance	–	6.1 KOhm
Analog Load Impedance	–	50 KOhm (V) - 600 Ohm (A)
Max Current per Discrete Output (Resistive)	4 A	4 A
Max Voltage per Discrete Output	240 VAC/DC	240 VAC/DC
Resistance per Discrete Output	25 mOhm	25 mOhm
Communication Control IN/OUT	–	MODBUS RS 485
Comm. Baud Rate	–	9600, 19200, 57600 Baud
Comm Available Registers	–	12
Local Signaling	Multicolor LED	Multicolor LED
Manual Remote Signaling	–	Supported**
Event Scheduler	–	Supported**
User Interface	–	OLED w/full navigation Keypad
Electrical Interconnections	Field Attachable Type A,C	Field Attachable Type A,C Customization Supported
Fail Safe	–	Supported***
Enclosure	GF-PP	GF-PP
Weight (kg/lbs)	1.25kg / 2.75 lbs.	1.25kg / 2.75 lbs.
Drive Socket	14 mm Double Square	14 mm Double Square

*20 / 177 (Nm/ in-lbs.) available with voltage specific motors with extended cycle times; consult factory. ** Outdoor applications consult factory. ***Additional Module Required.
Battery pack for Fail Safe operation is not operator replaceable. Consult factory.


DIMENSIONS



INSTALLATION



MODEL	SIZE		L		L1		L2		H		H1		W		W1	
	IN	DN	IN	MM	IN	MM	IN	MM	IN	MM	IN	MM	IN	MM	IN	MM
CAFE/CAFEN-037	3/8"	16	4.13	104.8	7.40	187.8	4.05	102.9	6.48	164.7	2.75	69.9	3.73	94.6	4.00	101.6
CAFE/CAFEN-050	1/2"	20	4.13	104.8	7.40	187.8	4.05	102.9	6.48	164.7	2.75	69.9	3.73	94.6	4.00	101.6
CAFE/CAFEN-075	3/4"	25	4.75	120.7	7.40	187.8	4.05	102.9	6.90	175.2	3.25	82.6	3.73	94.6	4.00	101.6
CAFE/CAFEN-100	1"	32	5.38	135.5	7.40	187.8	4.05	102.9	7.25	184.1	3.81	96.8	3.73	94.6	4.00	101.6
CAFE/CAFEN-125	1¼"	40	6.7	170.2	7.40	187.8	4.05	102.9	7.87	199.9	5.00	127.0	3.73	94.6	4.00	101.6
CAFE/CAFEN-150	1½"	50	6.75	171.5	7.40	187.8	4.05	102.9	7.87	199.9	5.00	127.0	3.73	94.6	4.00	101.6
CAFE/CAFEN-200	2"	63	7.90	200.7	7.40	187.8	4.05	102.9	7.87	199.9	5.56	141.2	3.73	94.6	4.00	101.6



MOUNTABLE IN ALL ORIENTATIONS



INSTALLATION

MOUNTING TO PLAST-O-MATIC BALL VALVE

1. Ensure the ball valve and the actuator are set to the closed position. The ball valve stem must be perpendicular to the flow direction, see drawing view
2. Thread the (2) mounting studs (item 3) into the mounting plate (item 2). Refer to the mounting plate detail view to determine which holes in the mounting plate are used for the appropriate valve size. Thread the studs into the bracket so that they are approximately flush with the top of the mounting plate. Use of a thread locking fluid, such as Loctite threadlocker is recommended.
3. Install the mounting plate (item 2) onto the actuator (item 1) using the (4) Assembly screws (item 4). Tighten to 40 in.lbs. Use of a thread locking fluid, such as Loctite threadlocker is recommended.
4. Install the coupler (item 5) onto the shaft of the ball valve (item 7). Assemble the ball valve (item 7) onto the actuator (item 1). The coupler (item 5) is inserted into the output drive of the actuator and the mounting studs go through the spacers (item 6) and the ball valve mounting lugs.
5. Install the hex nuts (item 8) onto the mounting studs (item 3) and tighten. For 3/8"-1" valves, tighten to 15 in.Lbs. for 1-1/4" - 2" valves, tighten to 25 in.Lbs.

Mounting Kit Components		
Item No.	Description	Qty.
1	Cafe or Cafe Nitro Actuator	1
2	Mounting Plate	1
3	Mounting Studs	2
4	Assembly Screws	4
5	Coupler	1
6	Spacers	2
7	2-Way or 3-Way Ball Valve	1
8	Hex Nuts	2

MOUNTING PLATE DETAIL



WIRING



Protection against electric shock - Class I device (earthed device).
All pole disconnection is required. Use copper conductors only.



BEFORE connecting, ensure the voltage to be applied is within the range shown on the ID label. Do NOT connect a voltage in excess of the intended design or irreparable damage will be caused and will NOT be covered by our warranty. Actuator Power Supply must be on a dedicated circuit and must be grounded.




CAFE actuators are multi-voltage capable with automatic voltage sensing. All connections are made using the supplied external DIN plugs. The rotation is factory set so under normal circumstances there is no need to remove the cover to connect electrically – removing the cover invalidates the warranty.



Water tightness: Ensure that all rubber gaskets are correctly installed when securing the Field attachable connectors to the actuator. Failure to do so could allow water ingress. Damage caused by this installation error will invalidate any warranty. Do not over-tighten the securing screw. Note that the profile gasket is part of the Field attachable connector.

ON/OFF WIRING

(3 WIRES AC/DC)



	PINOUT	INPUT POWER				ANALOG IN/OUT				DISCRETE OUTPUT (RELAYS)			
		1	2	3	⏏	1	2	3	⏏	1	2	3	⏏
ON	AC	(N)	–	(L)	(GND)	–	–	–	–	COMMON		*ON	–
	DC	(-)	–	(+)	(GND)	–	–	–	–	COMMON		*ON	–
OFF	AC	(N)	(L)	–	(GND)	–	–	–	–	COMMON	**OFF		–
	DC	(-)	(+)	–	(GND)	–	–	–	–	COMMON	**OFF		–
TA	AC	(N)	(L)	(L)	(GND)	–	–	–	–	COMMON	–	–	–
	DC	(-)	(+)	(+)	(GND)	–	–	–	–	COMMON	–	–	–




DISCRETE OUTPUTS: Chart indicates settings from Factory. Configuration can be changed via User Interface. *The corresponding Relay closes to indicate ON position **The corresponding relay closes to indicate OFF position

TA: Third Angle position. See page 35.

ON/OFF WIRING

(2 WIRES DC)




PINOUT	INPUT POWER				ANALOG IN/OUT				DISCRETE OUTPUT (RELAYS)				
	1	2	3	⏏	1	2	3	⏏	1	2	3	⏏	
ON	-	-	-	-	-	-	-	-	-	-	-	-	-
	DC	-	(-)	(+)	(GND)	-	-	-	-	COMMON	-	*ON	-
OFF	-	-	-	-	-	-	-	-	-	-	-	-	-
	DC	-	(+)	(-)	(GND)	-	-	-	-	COMMON	**OFF	-	-



DISCRETE OUTPUTS: Chart indicates settings from Factory. Configuration can be changed via User Interface *The corresponding Relay closes to indicate ON position **The corresponding relay closes to indicate OFF position

MODULATION WIRING

(mA) OR (V)




PINOUT	INPUT POWER				ANALOG IN/OUT				DISCRETE OUTPUT (RELAYS)			
	1	2	3	⏏	1	2	3	⏏	1	2	3	⏏
AC	(N)	(L)	–	(GND)	COMMON	IN	OUT	–	COMMON	**OFF	*ON	–
DC	(-)	(+)	–	(GND)	COMMON	IN	OUT	–	COMMON	**OFF	*ON	–



DISCRETE OUTPUTS: Chart indicates settings from Factory. Configuration can be changed via User Interface. *The corresponding Relay closes to indicate ON position **The corresponding relay closes to indicate OFF position

MODULATION WIRING

MODBUS




PINOUT	INPUT POWER				MODBUS				DISCRETE OUTPUT (RELAYS)			
	1	2	3	⏏	1	2	3	⏏	1	2	3	⏏
AC	(N)	(L)	–	(GND)	COMMON	A-D-D0	B+D+D1	–	COMMON	**OFF	*ON	–
DC	(-)	(+)	–	(GND)	COMMON	A-D-D0	B+D+D1	–	COMMON	**OFF	*ON	–




DISCRETE OUTPUTS: Chart indicates settings from Factory. Configuration can be changed via User Interface. *The corresponding Relay closes to indicate ON position **The corresponding relay closes to indicate OFF position

INPUT/OUTPUT WIRING


INTERNAL CONFIGURATIONS




(ON/OFF) DISCRETE CONTROL INPUT POWER




(MODULATION) ANALOGUE CONTROL IN/OUT



(MODBUS) COMM. CONTROL RS 485



(ALL MODELS) DISCRETE OUTPUTS VOLTAGE FREE RELAYS




INPUT/OUTPUT WIRING


TYPICAL APPLICATION WIRING




(ON/OFF) DISCRETE CONTROL INPUT – INPUT POWER - 3 WIRES, AC/DC




(ON/OFF) DISCRETE CONTROL INPUT – INPUT POWER - 2 WIRES, DC




(MODULATION) ANALOGUE CONTROL IN/OUT



(MODBUS) COMM. CONTROL - RS485



(ALL MODELS) DISCRETE OUTPUTS – VOLTAGE FREE RELAYS



INPUT/OUTPUTS

MODBUS REGISTRY TABLE



ModBus	Register	Description	Name	Displays	Value (Default Prog)	Min Value	Max Value	Read / Write
High	40000	Fault Code	-	STATUS, ALARMS	0	0	6	R
			Overload	STATUS, ALARMS	1			R
			Over Temp	STATUS, ALARMS	2			R
			Power Loss	STATUS, ALARMS	3			R
			Signal Loss	STATUS, ALARMS	4			R
			Hard. Fault	STATUS, ALARMS	5			R
			Dual Signal	STATUS, ALARMS	6			R
Low		Input Mode	0-10 V	STATUS, ANALOG IN	0	0	11	R/W
			2-10 V	STATUS, ANALOG IN	1			R/W
			0-20 mA	STATUS, ANALOG IN	2			R/W
			4-20 mA	STATUS, ANALOG IN	3			R/W
	ON/OFF		STATUS	4	R/W			
	MODBUS		STATUS	5	R/W			
	RTC		STATUS	6	R/W			
	Problem		STATUS	8	R/W			
	Keypad		STATUS	9	R/W			
	Calibration		STATUS	10	R/W			
	Manual		STATUS	11	R/W			
High Low	40001	Current Position	Position	STATUS	0	0	100	R
High Low	40002	Set Point	Setpoint	STATUS, KEYPAD CONTROL	0	0	100	R/W
High Low	40003	Load Motor	Load	HARD. MONITOR	0	0	3000	R
High Low	40004	Battery Voltage	Battery	HARD. MONITOR	829	0	900	R
High Low	40005	Micro Processor Temperature	Int Temp (°C/°F)	HARD. MONITOR	25	0	80	R
High	40006	Power Loss	Open	POWER LOSS	0	0	3	R/W
			Close		1			R/W
			Hold		2			R/W
			Angle		3			R/W
Low		Signal Loss	Open	COMM LOSS	0	0	3	R/W
			Close		1			R/W
			Hold		2			R/W
			Angle		3			R/W
High	40007	Relay 1 Configuration	Status Open	RELAY 1	0	0	4	R/W
			Status Close		1			R/W
			Fault		2			R/W
			Force Close		3			R/W
			Force Open		4			R/W
Low		Relay 2 Configuration	Status Open	RELAY 2	0	0	4	R/W
			Status Close		1			R/W
			Fault		2			R/W
High	40008	Language Configuration	English	LANGUAGE	0	0	1	R/W
			Español		1			R/W
Low	40008	Third Angle Percentage	Angle TA3	ANGLE TA3	50	0	100	R/W
High Low	40009	Speed Max Motor Value	Speed Max	NONE	2500	250	2500	
High	40010	Overload Time Configuration	Persist	OVERLOAD	0	0	3	R/W
			1 Sec		1			R/W
			2 Sec		2			R/W
			3 Sec		3			R/W
Low	40010	Dead Band Configuration	Dead Band	DEAD BAND	0	0	5	R/W
High Low	40011	Default Close Position Sensor Value	Set Closed	CALIBRATION	680	50	4050	R/W
High Low	40012	Default Open Position Sensor Value	Set Opened	CALIBRATION	1724	50	4050	R/W
High Low	40013		Spare					
High Low	40014		Spare					

OPERATION

FEATURES




OPERATION

FEATURES






Manual Override: Use a 4 mm hex wrench to drive the actuator manually. Rotating the manual drive counter clockwise will open the valve in a standard orientation. Rotating the manual drive clockwise will close a valve that is in the open position.



Visual indicator: Graphically indicates the approximate position of the valve with respect to the full working angle. Typical working angles are 90° or 180°. For a valve that has been set up as Normally Closed, the indicator will move from 0° to Max Working angle when opening. The action is reversed when closing the valve.

LED Ring Indicator: The base ring of the barrel type indicator will illuminate according to different states of running conditions in the actuator. See chart "LED RUNNING STATES"



Key Pad: Center pad  is SELECT. Use the fully directional key pad to navigate the menu. When driving the actuator in key pad control, the  pad rotates the actuator counter clockwise. When driving the actuator in Keypad Control the  pad rotates the actuator clockwise.

OPERATION


LED RING INDICATOR RUNNING STATES

ON/OFF ACTUATOR

1. No power detected
2. In position open
3. In position close
4. Opening
5. Closing
6. Torque limit engaged, moving from close to open
7. Torque limit engaged, moving from open to close
8. Actuator in MANUAL or KEYPAD mode
9. Dual signal (third angle)
10. Over temperature
11. Overload

ACTUATOR OPERATIONAL STATUS


(200 msec/block)



MODULATING ACTUATOR

1. No power detected
2. In position open
3. In position close
4. Opening
5. Closing
6. Torque limit engaged, moving from close to open
7. Torque limit engaged, moving from open to close
8. Actuator in MANUAL or KEYPAD mode
9. Actuation feedback complete
10. Signal loss
11. Over temperature
12. Overload

ACTUATOR OPERATIONAL STATUS




OPERATION

LED RING INDICATOR RUNNING STATES

MODBUS ACTUATOR

1. No power detected
2. In position open
3. In position close
4. Opening
5. Closing
6. Torque limit engaged, moving from close to open
7. Torque limit engaged, moving from open to close
8. Actuator in MANUAL or KEYPAD mode
9. Actuator feedback complete
10. Over temperature
11. Overload


ACTUATOR OPERATIONAL STATUS



FAIL SAFE ACTUATOR

1. No power detected - fail safe
2. In position open
3. In position close
4. Opening
5. Closing
6. Torque limit engaged, moving from close to open
7. Torque limit engaged, moving from open to close
8. Actuator in MANUAL or KEYPAD mode
9. Dual signal (third angle)
10. Signal loss
11. Over temperature
12. Overload

ACTUATOR OPERATIONAL STATUS



OPERATION

LED RING INDICATOR RUNNING STATES

No power detected: LED ring indicator is off. The power circuit that feeds the actuator has been turned off.

In position open: LED ring indicator is steady green. The actuator has reached the max. working angle. Typically 90° or 180°. A valve that has been set up as Normally Closed, is now fully open.

In position closed: LED ring indicator is steady blue. The actuator is at the minimum working angle. Typically 0°. A valve that has been set up as Normally Closed, is now fully closed.

Opening: LED ring indicator blinks yellow and green for the length of the run. In the case of ON/OFF actuators the run goes from closed to open. In the case of Modulating or Modbus actuators the run is according to the proportional control signal.

Closing: LED ring indicator blinks yellow and blue for the length of the run. In the case of ON/OFF actuators the run goes from open to close. In the case of Modulating or Modbus actuators the run is according to the proportional control signal.

Torque Limit engaged, moving from close to open: LED ring indicator blinks green indicating that the actuator has reached 80% of the load limit for the length of the run. Actuator will operate normally. In the case of ON/OFF actuators the run goes from closed to open. In the case of Modulation or Modbus actuators the run is according to the proportional control signal when opening the valve.

Torque Limit engaged, moving from open to close: LED ring indicator blinks blue indicating that the actuator has reached 80% of the load limit for the length of the run. In the case of Modulation or Modbus actuators the run is according to the proportional control signal when closing the valve.

Actuator in MANUAL or KEYPAD mode: LED ring indicator blinks yellow indicating, that the actuator is in manual mode. Actuator can be controlled via the keypad or 4mm Hex Wrench, depending on the setting. Only available on actuators with Display and keypad.

Dual Signal (Third Angle): Only available for ON/OFF actuators with Display and keypad. LED ring indicator blinks pink indicating that the actuator has received two control signals. The default setting for this condition is 50 % of the working angle.

Over Temperature: Critical Alarm. LED ring indicator bursts in a set of 3 red blinks, indicating that the max. internal safe operating temperature has been reached. The actuator will not operate until the internal temperature falls below the threshold or the cause of rise in temperature has been removed.

Overload: Critical Alarm. LED ring indicator bursts in a set of 4 red blinks, indicating that the max. torque has been reached. The actuator will fall into this alarm for as long as the overload condition persist. The actuator will stop within one second. CAFEN Actuators can modify this behavior from the Overload menu.

Actuation feedback complete: Only available for Modulating and Modbus CAFEN Actuators. Yellow LED indicator indicates that the propositional position has been reached.

Signal Loss: Critical Alarm. Only available for CAFEN Actuators set to Modulation control signal 2-10V or 4-20 mA. LED ring indicator bursts in a set of 2 red blinks, indicating that the proportional control signal is lost. The actuator will recover from this alarm once the control signal is reestablished.

NO Power Detected. Fail Safe: Critical Alarm. Only available for actuators with Fail Safe Kit. The LED ring indicator blinks red. The power circuit that feeds the actuator has been turned off and the Fail Safe condition has been activated. The actuator will recover from this alarm once the power is reestablished.


OPERATION

INITIALIZATION DISPLAY

WELCOME DISPLAY




FIRMWARE & HARDWARE VERSION INFORMATION




Indicates the type of Actuator:
ON/OFF, Modulating, or Modbus

STATUS DISPLAY



OPERATION

STATUS DISPLAY

STATUS display allows you to navigate between **MENU** and **DRIVE** Control. Using the directional keypad place the cursor  on the desired option and press SELECT.

STATUS display will indicate the type of input and output control signal according to the type of actuator.

ON/OFF: Only ON/OFF control. See wiring on pages 8 and 9.

MODULATING: Available options are V/V, mA/mA, V/mA, mA/V with additional combinations for 0-10V, 2-10V, 0-20 mA, and 4-20mA. See wiring on page 10.

MODBUS: Only Modbus control. See wiring on page 11.

The working angle can be set up from 0° to 3°.

Position in STATUS display indicates the actual position as a % of the working angle.

Setpoint in STATUS display indicates the desired position as a % of the working angle.


Power in STATUS display indicates the source of power. All actuators use Main as the default source. Actuators with Fail Safe will switch to Batt (Battery) at power loss.

STATUS display will show the last triggered alarm during a failed operation.

Triggered alarms during failed operation are: **power loss, over torque, over temperature, signal loss, concurrent signal, and hardware failure.**

OPERATION

MAIN MENU



MENU Display gives access to the root menu. The main menu is categorized as Alarms, Control, Language and Maintenance. Each category contains sub-menus that are specific to the type of actuator; ON/OFF, Modulating, Modbus.

Alarms: Enter this sub-menu to reset any of the triggered alarms presented in the STATUS display. A record of the last three alarms is kept in this sub-menu. Overload, Over Temp, and Hard Fault are considered critical alarms and must be reset via this menu. User should clear the condition that generated the alarm. Other alarms reset once the triggered condition is removed or restored.

Control: Enter this sub-menu to change settings that affect the way the actuator behaves with the control signals. These sub-menus are password protected by default. 0 0 0 0 is the default factory password. The password can be deactivated; see PASSWORD in CONTROL menu.

Language: Enter this sub-menu to select your preferred language. English and Español are available.

Maintenance: Enter this sub-menu to change settings that affect the way the actuator behaves with the external assembly; i.e. the mounted valve. These sub-menus are password protected by default. 0 0 0 0 is the default factory password. The password can be deactivated; see PASSWORD in CONTROL menu.

OPERATION

(ON/OFF) MAIN MENU AND SUB-MENU



OPERATION

(ON/OFF) MAIN MENU AND SUB-MENU

MENU

Alarms
Control
Language
> Maintenance



Record of the last three triggered alarms will be saved in display.

Scheduler is only available in ON/ OFF actuators with Display, Keypad and RTC kit. Consult Factory.

MAINTENANCE

> Calibration
Overload
Hysteresis
Drive


NEXT

MAINTENANCE

Relay Options
Third Angle
Factory Setting


OPERATION

(ON/OFF) CONTROL AND SUB-MENU OPTIONS



OPERATION

(ON/OFF) CONTROL AND SUB-MENU OPTIONS



OPERATION Normal Closed operation is the default. Actuator will close a valve when responding to an OFF signal or minimum proportional control value. Actuator will open a valve when responding to an ON signal or max. proportional control value. Normal Open is the reverse operation. Always save the selection.

SPEED 100% is the default . Move the cursor to "increase" or "decrease" and then press **O** to change %.

POWER LOSS At power loss, Fail Safe actuators will close by default. Use the key pad to change the selection. ANGLE allows the user to set a desired fail position within the working angle at power loss.

DEAD BAND Default setting is 0%. Move cursor to "increase" or "decrease" and then press **O** to change % in relation to working angle up to 5%. Always save the selection.

HARDWARE MONITOR Keeps track of important parameters of the actuator. Run Time is a counter of each continuous run regardless of the direction

ANTICONDENSATION ON is the default. 82° F is the default threshold. Below the threshold a internal heater will turn ON. The threshold can be turned OFF to prevent the heater from turning ON. Always save the selection.

PASSWORD ON is the default. Change password by entering a New Password. 0 0 0 0 is the factory default password. Move the cursor to PASSWORD and press **O** to deactivate the password protection. Enter your password and select OK. Always save the selection. ALWAYS REMEMBER YOUR NEW PASSWORD. Losing your new PASSWORD will prevent you from changing password protected settings.

LED Default setting is ON. Allows the user to turn off the LED Ring Indicator ON or OFF.

OPERATION

MENU
> Hardware Monitor
Anticondensation
Password
Scheduler

MENU
Hardware Monitor
> Anticondensation
Password
Scheduler

MENU
> Hardware Monitor
Anticondensation
Password
Scheduler

HARDWARE MONITOR
Load: 0 mA
Int. Temp: 130°F
Battery: 8.52 V
Run Time: 15

> MENU

ANTICONDENSATION
82°F
Increase
Decrease
ON

> SAVE MENU

PASSWORD ON/OFF
Old Password
0000
New Password
0000

> SAVE MENU

MENU
Dead Band
Hardware Monitor
Anticondensation
Password
> LED

LOGIN ON/OFF
Enter Password
0000

>OK NO

LED
ON*
OFF

>SAVE

OPERATION





(ON/OFF) CONTROL AND SUB-MENU OPTIONS



SCHEDULER Selected models include an Event scheduler . Two events for valve OPEN/ CLOSE can be set up per day . This feature must be turned ON prior to being used. DATE & TIME must be updated for the internal clock to synchronize with the real time clock.

Always save the selection.

Discrete Control Inputs are inactive while the SCHEDULER is ON in order to prevent undesired control results.



OPERATION

(ON/OFF) MAINTENANCE AND SUB-MENU OPTIONS

MAINTENANCE
>Calibration
Overload
Hysteresis
Drive
NEXT

MAINTENANCE
Calibration
>Overload
Hysteresis
Drive
NEXT

MAINTENANCE
Calibration
Overload
>Hysteresis
Drive
NEXT



CALIBRATION
Move
Position **675**
Set Closed
Set Opened
>SAVE MENU

OVERLOAD
1 sec *
2 sec
3 sec
Persist
>SAVE MENU

HYSTERESIS
0%
Increase
Decrease
>SAVE MENU

OPERATION

(ON/OFF) MAINTENANCE AND SUB-MENU OPTIONS



CALIBRATION Use this display to set the closed and open position for the actuator. Select "Move" and then use < > to rotate counter clockwise or clockwise respectively. After the desired point is achieved select Set Closed or Set Opened. Repeat same operation for the other point. Always SAVE the selection.

OVERLOAD Use this display to set the time delay for overload detection. Default is 1 second. Persist will keep trying the operation 5 consecutive times. Always SAVE the selection.


HYSTERESIS Use this display to compensate for any backlash that appears overtime in the link between actuator and the valve stem. Max value is 5 °.

DRIVE Select your method of control. While in Keypad or Manual, the actuator will not respond to control signals. Auto is the default. Always SAVE the selection.

OPTIONAL A signal can be set for keypad or manual selection

OPERATION

(ON/OFF) MAINTENANCE AND SUB-MENU OPTIONS



OPERATION

(ON/OFF) MAINTENANCE AND SUB-MENU OPTIONS

MAINTENANCE
Relay Outputs
Third Angle
> Factory Setting

FACTORY SETTINGS
> Keep Settings
Factory Set.


FACTORY SETTINGS
Enter Password

0 0 0 0

>SAVE MENU

OPERATION

(MODULATION) MAIN MENU AND SUB-MENU





OPERATION

(MODULATION) MAIN MENU AND SUB-MENU




Record of the last three triggered alarms will be saved in display. Overload, Over Temp, and Hard Fault are considered critical alarms and must be reset via this menu. User should clear the condition that generated the alarm. Other alarms reset once the triggered condition is removed or restored.



OPERATION

(MODULATION) CONTROL AND SUB-MENU OPTIONS



OPERATION

(ON/OFF) CONTROL AND SUB-MENU OPTIONS

MENU

Operation
Speed
Power loss
> Comm Loss

NEXT

COMM LOSS

Open
Close*
Hold
Angle

>SAVE MENU


ANGLE

50 %
Increase
Decrease

>SAVE MENU

OPERATION

(MODULATION) CONTROL AND SUB-MENU OPTIONS



OPERATION

(MODULATION) CONTROL AND SUB-MENU OPTIONS

MENU

Dead Band
Hardware Monitor
Anticondensation
> Password
LED



DEAD BAND Default setting is 0%. Move cursor to "increase" or "decrease" and then press **○** to change % in relation to working angle up to 5%. Always save the selection.

HARDWARE MONITOR Keeps track of important parameters of the actuator. Run Time is a counter of each continuous run regardless of the direction

ANTICONDENSATION ON is the default. 82° F is the default threshold. Below the threshold a internal heater will turn ON. The threshold can be turned OFF to prevent the heater from turning ON. Always save the selection.

PASSWORD ON is the default. Change password by entering a New Password. 0 0 0 0 is the factory default password. Move the cursor to PASSWORD and press **○** to deactivate the password protection. Enter your password and select OK. Always save the selection. ALWAYS REMEMBER YOUR NEW PASSWORD. Losing your new PASSWORD will prevent you from changing password protected settings.

LED Default setting is ON. Allows the user to turn off the LED Ring Indicator ON or OFF.

MENU

Dead Band
Hardware Monitor
Anticondensation
Password
> LED

PASSWORD ON/OFF

Old Password
0 0 0 0
New Password
0 0 0 0

>SAVE MENU

LED

ON*
OFF

>SAVE

LOGIN ON/OFF

Enter Password
0 0 0 0

>OK NO

OPERATION

(MODULATION) MAINTENANCE & SUB-MENU OPTIONS

MAINTENANCE
> Calibration
Analog In
Analog Out
Compensation

NEXT

MAINTENANCE
Calibration
> Analog In
Analog Out
Compensation

NEXT

MAINTENANCE
Calibration
Analog In
> Analog Out
Compensation

NEXT

CALIBRATION
Move
Position: 675
Set Closed
Set Opened

>SAVE MENU

ANALOG IN
> 0-10 V*
2-10 V
0-20 mA
4-20 mA



>SAVE MENU

ANALOG OUT
> 0-10 V*
2-10 V
0-20 mA
4-20 mA

>SAVE MENU

OPERATION

(MODULATION) MAINTENANCE & SUB-MENU OPTIONS



CALIBRATION Use this display to set the closed and open position for the actuator. Select "Move" and then use < > to rotate counter-clockwise or clockwise respectively. After the desired point is achieved select Set Closed or Set Opened. Repeat same operation for the other point. Always SAVE the selection


ANALOG IN Use this display to set the type of input control signal for the proportional control. Always SAVE the selection

ANALOG OUT Use this display to set the type of output control signal for the proportional control. Always SAVE the selection

COMPENSATION Use this display to set an increase in the feedback signal in order to compensate for unwanted transmission losses. Max. 10% . Default is 0% Always SAVE the selection



OPERATION

(MODULATION) MAINTENANCE & SUB-MENU OPTIONS



OPERATION

(MODULATION) MAINTENANCE & SUB-MENU OPTIONS





OVERLOAD Use this display to set the time delay for overload detection. Default is 1 sec. Persist will keep trying the operation 5 consecutive times. Always SAVE the selection

HYSTERESIS Use this display to compensate for any backlash that appears overtime in the link between actuator and the valve stem. Max value is 5 °.

DRIVE Select your method of control. While in Keypad or Manual, the actuator will not respond to control signals. Auto is the default. Always SAVE the selection.


RELAY OUTPUT Use this display to set the type response you want from the discrete outputs. By default Relay 1 is set to indicate the ON (Open condition) and Relay 2 is set to indicate OFF (Closed condition) Always SAVE the selection

FACTORY SETTING Is always password protected regardless if PASSWORD is ON or OFF. Actuator will go back to original settings from factory. 0 0 0 0 is the factory default password. Always save the selection.




OPERATION

(MODBUS) MAIN MENU AND SUB-MENU



OPERATION

(MODBUS) MAIN MENU AND SUB-MENU



OPERATION

(MODBUS) CONTROL AND SUB-MENU OPTIONS

MENU
> Operation
Speed
Power loss
Comm Loss

NEXT

MENU
Operation
> Speed
Power loss
Comm Loss

NEXT

MENU
Operation
Speed
> Power loss
Comm Loss

NEXT

OPERATION
Normal Closed*
Normal Opened

> SAVE MENU

SPEED
100 %
Increase
Decrease

> SAVE MENU

POWER LOSS
Open
Close*
Hold
> Angle

> SAVE MENU

OPERATION Normal Closed operation is the default. Actuator will close a valve when responding to an OFF signal or minimum proportional control value. Actuator will open a valve when responding to an ON signal or max. proportional control value. Normal Open is the reverse operation. Always save the selection.

SPEED 100% is the default . Move the cursor to "increase" or "decrease" and then press **O** to change %.

POWER LOSS At power loss, Fail Safe actuators will close by default. Use the key pad to change the selection. ANGLE allows the user to set a desired fail position within the working angle at power loss.

COMM LOSS Activates when control signal is lost. By default the setting is Hold. Only available for control signals 2-10V, 4-20 mA. Always save the selection.

ANGLE
50 %
Increase
Decrease

> SAVE MENU

OPERATION

(MODBUS) CONTROL AND SUB-MENU OPTIONS

MENU

Operation
Speed
Power loss
> Comm Loss

NEXT

COMM LOSS

Open
Closed
Hold*
> Angle

> SAVE MENU


ANGLE

50 %
> Increase
Decrease

> SAVE MENU

OPERATION

(MODBUS) CONTROL AND SUB-MENU OPTIONS



OPERATION

(MODBUS) CONTROL AND SUB-MENU OPTIONS

MENU
Dead Band
Hardware Monitor
Anticondensation
> Password

PASSWORD ON/OFF
Old Password
0 0 0 0
New Password
0 0 0 0
> SAVE MENU

LOGIN ON/OFF
Enter Password
0 0 0 0
> OK NO

MENU
Dead Band
Hardware Monitor
Anticondensation
Password
> LED

LED
ON*
OFF
>SAVE



DEAD BAND Default setting is 0%. Move cursor to "increase" or "decrease" and then press **O** to change % in relation to working angle up to 5%. Always save the selection.

HARDWARE MONITOR Keeps track of important parameters of the actuator. Run Time is a counter of each continuous run regardless of the direction


ANTICONDENSATION ON is the default. 82° F is the default threshold. Below the threshold a internal heater will turn ON. The threshold can be turned OFF to prevent the heater from turning ON. Always save the selection.

PASSWORD ON is the default. Change password by entering a New Password. 0 0 0 0 is the factory default password. Move the cursor to PASSWORD and press **O** to deactivate the password protection. Enter your password and select OK. Always save the selection. ALWAYS REMEMBER YOUR NEW PASSWORD. Losing your new PASSWORD will prevent you from changing password protected settings.

LED Default setting is ON. Allows the user to turn off the LED Ring Indicator ON or OFF.




OPERATION

(MODULATION) MAINTENANCE & SUB-MENU OPTIONS



OPERATION

(MODBUS) MAINTENANCE & SUB-MENU OPTIONS




CALIBRATION Use this display to set the closed and open position for the actuator. Select "Move" and then use < > to rotate counter-clockwise or clockwise respectively. After the desired point is achieved select Set Closed or Set Open. Repeat same operation for the other point. Always SAVE the selection.

COMPENSATION Use this display to set an increase in the feedback signal in order to compensate for unwanted transmission losses. Max. 10% . Default is 0% Always SAVE the selection.

NETWORK Use this display to set the node of the actuator within the Modbus network. Node and baud rate must be set in advance and in accordance to the existing network. Node 1 and 19200 baud are the default settings. Always save the selection.


OPERATION

(MODBUS) MAINTENANCE & SUB-MENU OPTIONS



OPERATION

(MODBUS) MAINTENANCE & SUB-MENU OPTIONS



OVERLOAD Use this display to set the time delay for overload detection. Default is 1 sec. Persist will keep trying the operation 5 consecutive times. Always SAVE the selection

HYSTERESIS Use this display to compensate for any backlash that appears overtime in the link between actuator and the valve stem. Max value is 5 °.

DRIVE Select your method of control. While in Keypad or Manual, the actuator will not respond to control signals. Auto is the default. Always SAVE the selection.

RELAY OUTPUT Use this display to set the type response you want from the discrete outputs. By default Relay 1 is set to indicate the ON (Open condition) and Relay 2 is set to indicate OFF (Closed condition) Always SAVE the selection

FACTORY SETTING Is always password protected regardless if PASSWORD is ON or OFF. Actuator will go back to original settings from factory. 0 0 0 0 is the factory default password. Always save the selection.



USA Engineered

ENGINEERED & ASSEMBLED IN USA

plastomatic.com

PLASTOMATIC

Plast-O-Matic Valves, Inc.

1384 Pompton Avenue
Cedar Grove, NJ 07009 USA

(973) 256.3000

Fax (973) 256.4745